



MVE Unpacking Procedure

1. Remove the screws securing the starter to the pallet (4 per phase arm).



2. Connect a lifting hook to the phase arm and lift slowly upward. DO NOT lift by hand.

